

Accessories

○Connector cable

| | SI unit connector | Suitable connector | | | |
|---|------------------------------|--|--|--|--------------|
| | | Description | Part number | Specifications | Manufacturer |
| 1 | Fieldbus interface connector | Cable with communication connector | EX9-AC010EN-PSRJ: 1 m EX9-AC020EN-PSRJ: 2 m EX9-AC030EN-PSRJ: 3 m EX9-AC050EN-PSRJ: 5 m EX9-AC100EN-PSRJ: 10 m | Connector: M12 straight at one end and RJ45 at the other end | SMC |
| | | | PCA-1446566 | Connector: M12 straight Cable: 5 m | |
| | | Fieldwireable connector | PCA-1446553 | Connector: M12 straight plug | |
| 2 | Power supply connector | Cable with power supply connector | EX500-AP010-S | Connector: M12 straight Cable: 1 m | |
| | | | EX500-AP050-S | Connector: M12 straight Cable: 5 m | |
| | | | EX500-AP010-A | Connector: M12 angle Cable: 1 m | |
| | | | EX500-AP050-A | Connector: M12 angle Cable: 5 m | |
| | | Cable with power supply connector (for SPEEDCON) | PCA-1401804 | Connector: M12 straight Cable: 1.5 m | |
| | | | PCA-1401805 | Connector: M12 straight Cable: 3 m | |
| | | | PCA-1401806 | Connector: M12 straight Cable: 5 m | |

○Seal cap (10 pcs.)

This cap is used to protect the M12 connector opening when the connector is not used. When the "BUS OUT" connector is not used, the seal cap can keep the SI unit under IP67 rated protection. (One seal cap will be attached to the SI unit when shipped from factory.)



| Description | Part No. | Specification |
|-------------|----------|-----------------------------------|
| Seal cap | EX9-AWTS | For M12 connector socket: 10 pcs. |